

MEMOCam[®]

POCKET PC PLAYER

USER GUIDE

Version 1.0.002



4/20/2003 11:54 AM

TABLE OF CONTENTS

<i>Introducing the MemoCam Player.....</i>	<i>1</i>
<i>Installing the MemoCam Player.....</i>	<i>2</i>
Installing Using the Multimedia Card (Option A)	2
Installing from a PC Using ActiveSync (Option B)	3
Installing from the Internet (Option C)	3
Uninstalling the MemoCam <i>Player</i>	3
<i>Using the MemoCam Player</i>	<i>5</i>
Using the MemoCam Image <i>Player</i>	6
<i>Viewing Individual Images</i>	6
<i>Playing Consecutive Images</i>	6
<i>Using the Image Player Toolbar</i>	8
Using the MemoCam List Window	9

INTRODUCING THE MEMOCAM *PLAYER*

The MemoCam® *Pocket PC Player* (MemoCam *Player*) is a mobile version of the MemoCam PC application that runs on Pocket PC compatible devices. The MemoCam *Player* enables quick on-site viewing of MemoCam's images from the Multimedia card. The MemoCam *Player* is easy to use and provides you with maximum player flexibility when analyzing your images.

INSTALLING THE MEMOCAM *PLAYER*

You can install the MemoCam *Player* on your Pocket PC with WIN CE 3.0 or higher (Windows Pocket PC), in any of the following ways:

- ☐ Using the Multimedia card (Option A).
- ☐ From a PC using ActiveSync (Option B).
- ☐ From the Internet (Option C).

Each of these procedures is described below.

The MemoCam *Player* installation places the **MemoCam** icon in the **Start** menu of your Pocket PC. The MCP_Arm.cab file is automatically deleted after installation.



To upgrade the existing version of the MemoCam Player on your Pocket PC, follow the directions below for installing the MemoCam Player.

Installing Using the Multimedia Card (Option A)

To install the MemoCam *Player* using the Multimedia card:

1. Insert your Multimedia card into the reader connected to your desktop computer.
2. Copy **MCP_Arm.cab** from the \PocketPC directory on the installation CD-ROM to the Multimedia card.
3. Remove the Multimedia card from the reader and insert it into your Pocket PC's slot.

4. Double-tap the .cab file on your Pocket PC. The MemoCam *Player* installation begins.
5. Follow the instructions displayed on your Pocket PC.

Installing from a PC Using ActiveSync (Option B)

To install the MemoCam *Player* from your desktop computer:

1. Connect your Pocket PC to your desktop computer and establish a session using Microsoft ActiveSync®.
2. Download **MCP_Arm.cab** from the \PocketPC directory on the installation CD-ROM to a temporary folder on your Pocket PC using ActiveSync.
3. Double-tap the .cab file on your Pocket PC. The MemoCam *Player* installation begins.
4. Follow the instructions displayed on your Pocket PC.

Installing from the Internet (Option C)

To install the MemoCam *Player* from the Internet:

1. Download **MCP_Arm.cab** from the \PocketPC directory on the installation CD-ROM to a temporary folder on your Pocket PC using your Pocket PC's Internet connection.
2. Double-tap the .cab file on your Pocket PC. The MemoCam *Player* installation begins.
3. Follow the instructions displayed on your Pocket PC.

Uninstalling the MemoCam *Player*


To uninstall the MemoCam *Player* from your Pocket PC:

1. Open the **Start** menu and tap **Settings**. The Settings dialog box appears.
2. Tap **System** to open the System tab.
3. Tap **Remove Programs**.
4. Tap **MemoCam Pocket PC Player**.
5. Tap the **Remove** button to uninstall the MemoCam *Player*.

USING THE MEMOCAM *PLAYER*

To access the MemoCam *Player* on your Pocket PC:

1. Insert your Multimedia card into the slot on your Pocket PC.
2. Open the **Start** menu and tap **MemoCam**. The MemoCam List window appears with a list of images.



If there is no Multimedia card in the slot of your Pocket PC or the Multimedia card was removed from the slot, a demonstration file containing sample images will open.

Using the MemoCam Image *Player*


Use the MemoCam Image *Player* to view the images on the Multimedia card.

Viewing Individual Images

To view individual images :

Select the image, open the **Tools** menu and tap **View**. The selected image is displayed in the default picture editor on your Pocket PC.


OR

Double-tap an image in the Image List. The Image *Player* opens and begins to playback the image. Tap  on the toolbar and the selected image will display in the default picture editor.

Playing Consecutive Images

You can double-tap any of the images on the list to play all the images on the Multimedia card consecutively. Alternatively, you can open the **Tools** menu and tap **Play**.

The images are displayed one-by-one in the Image *Player*.

You can hide and display the Image *Player* toolbar by tapping .



Using the Image *Player* Toolbar

Use the buttons on the Image *Player* toolbar to control viewing the images.



Closes the Image *Player*.



Checks the image integrity. Enter the integrity key or load the key from a file. The key file must be located in the "My Documents" folder.



Displays the previous image.



Displays the next image.



Displays the current image in your Pocket PC's default viewer.



Pauses playing the images.



Plays the images backwards.



Plays the images forwards.



Adjusts the speed at which the images are displayed:

Up – faster.





Down – slower.



You can also pause and restart playing the images by tapping the image.

Using the MemoCam List Window

By using the MemoCam List window, you can:

- ❑ ***Change the Format of the List to Thumbnails.*** Open the **View** menu and tap **Thumbnails**, or click . The list of images is displayed as thumbnails.
- ❑ ***Change the Format of the List to a Table Format.*** Open the **View** menu and tap **Details**, or click . The list of images is displayed in table format.
- ❑ ***Filter the List.*** Open the **Tools** menu and tap **Filter**. A dialog box appears, enabling you to specify a range of dates and times, or camera numbers for the images you want to view. To cancel all the filters, tap the **Cancel** button in the Filter dialog box.
- ❑ ***Refresh the List.*** Open the **View** menu and tap **Refresh**. The contents of the list are updated from the Multimedia card.
- ❑ ***Sort the List by a Specific Columns Contents.*** Tap  to sort the list in ascending order and  to sort the list in descending order, according to the contents of the selected column.
- ❑ ***Clear the Event Files.*** Open the **Tools** menu and tap **Clear Event Files**. All the images files on the Multimedia card are deleted.
- ❑ ***View the MemoCam Version Number.*** Open the **Tools** menu and tap **About MemoCam**. The About MemoCam window with the version and firmware numbers is displayed.
- ❑ ***View Details of an Image.*** Open the **View** menu and tap **View Details**. A window with the serial and event

numbers, number of frames, trigger source and time, integrity check, video status, and camera number is displayed.

- ❑ **Rename the MemoCam Unit.** Open the **Tools** menu and tap **Rename MemoCam**. A window appears, enabling you to add a descriptive name to help you identify the MemoCam unit's location.
- ❑ **Check Image Integrity.** Open the **Tools** menu and tap **Check Image Integrity**. Enter the integrity key or load the key from a file. The key file must be located in the "My Documents" folder on your Pocket PC. Image integrity cannot be enabled or disabled using your MemoCam Player. To enable or disable image integrity, refer to the *MemoCam User Guide*.
- ❑ **Remove the MemoCam Application from Memory.** Open the **Tools** menu and tap **Exit**.



You can open the pop-up menu by long-tapping within the Image List. The pop-up menu contains most of the regular menu options.



The MemoCam Player contains no configuration facilities. To configure your MemoCam unit, refer to the MemoCam User Guide.
